29 January, 2015, www.brodit.com, © 2015 Brodit AB

# Product 855038

**855038 ProClip**

Center mount

The ProClip is a mounting bracket for the vehicle's dashboard. Onto the ProClip you can install e.g. a holder for your mobile phone or PDA or a handsfree set etc. Safe and convenient -always within easy reach. The ProClip is car specific and easy to install. The installation is quick, no special tools or dismantle of the dashboard is required and it will not damage the interior of the vehicle. Made in black ABS plastic. Comes with detailed instructions.

EAN: 7320288550381

**Item no 855038 fits:**
Ford Transit Courier 14-15 (For all countries)

**INSTALLATION INSTRUCTIONS**

1.

2.

3.

4.

Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the encclosed alcohol pad to clean the area where the ProClip is to be installed. Press the enclosed gap opener into the gap surrounding the center control panel, to widen the gap. Push the gap opener leftwards, to find the plastic detail hidden behind the panel that the ProClip needs to be fitted around. Remove the adhesive tape covers from the ProClip. Place the angled top part of the ProClip in its position guided by the gap opener.

2. Push the gap opener rightwards again to make room for the ProClip, and leave it in the gap to widen it. Press the angled top part of the ProClip into the gap next to the gap opener. Remove the gap opener.

3. Press the bottom part of the ProClip downward, so the angled top part hooks behind the panel properly. Press the angled bottom part of the ProClip into the gap underneath of the center console.

4. The ProClip is in place.